

z+1000

z+500

z+0 Context : [MACHINE\_POSITION\_1]

z-500

z-1000

z-1500

X Y Z

Context : [MACHINE\_POSITION\_1]

x+0

x-500

x-1000

x-1500

x-2000

x-2500

x-3000

x-3500

x-4000

x-4500

MODELLISTA  
STEZZANESE